

## NOTES:

- 1. CONTRACTOR SHALL STRIKE CONTROL JOINTS EVERY 5'-0" AND PLACE EXPANSION JOINTS EVERY 20'-0"
- 2. CONTRACTOR TO INSTALL 1/2" PREFORMED EXPANSION JOINT MATERIAL AT ALL EXPANSION JOINTS AND WHERE SIDEWALK ABUTS CONCRETE CURB, FOUNDATIONS, APRONS, OR OTHER CONCRETE STRUCTURES.
- 3. USE APPROVED SEALANT OVER ALL SIDEWALK EXPANSION JOINTS.



